

FIGURE 1
LCD MONITOR (M/N: E2350TV)
GENERAL APPEARANCE (FRONT VIEW)



FIGURE 2
LCD MONITOR (M/N: E2350TV)
GENERAL APPEARANCE (BACK VIEW)



FIGURE 3
LCD MONITOR (M/N: E2350TV)
PORTS



FIGURE 4
LCD MONITOR (M/N: E2350TV)
D-SUB CABLE #1



FIGURE 5
LCD MONITOR (M/N: E2350TV)
D-SUB CABLE #2



FIGURE 6
LCD MONITOR (M/N: E2350TV)
DVI CABLE #1



FIGURE 7
LCD MONITOR (M/N: E2350TV)
DVI CABLE #2



FIGURE 8
LCD MONITOR (M/N: E2350TV)
POWER CORD



FIGURE 9
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 GENERAL APPEARANCE




FIGURE 10
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 POWER PORT



FIGURE 12
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 COVER REMOVED



FIGURE 13
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 MAIN BOARD (COMPONENT SIDE)




FIGURE 14
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 MAIN BOARD GENERAL VIEW BACK




FIGURE 15
LCD MONITOR (M/N: E2350TV)
ADAPTER #1 MAIN BOARD (SOLDERED SIDE)




FIGURE 16
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 GENERAL APPEARANCE




FIGURE 17
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 POWER PORT



FIGURE 18
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 LABEL



FIGURE 19
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 COVER REMOVED




FIGURE 20
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 MAIN BOARD (COMPONENT SIDE)



FIGURE 21
LCD MONITOR (M/N: E2350TV)
ADAPTER #2 MAIN BOARD (SOLDERED SIDE)

