



Device Operation -

The 6005 Transmitter, when activated by one of its four or six momentary switches (model dependant) the unit transmits a modulated code. This code consists of a device address configured via DIP Switches and a 'device state' setting determined by which button is pressed. When a receiving device is programmed via jumpers to the same code as the transmitter, receives this code it then corresponds its output according the 'device state' portion of the code (on, off, flash, dim or brighten).