

## **Label Location Clarification**

Question : Label location looks like it is under a cover. This is not permitted please clarify how the label is visible to the end user.

Applicant Answer : The label is located in an area that the customer must access in order to use the device; which would be in a “conspicuous area” according to the FCC requirements. The device is packaged in 2 separate parts, the (Sensor module) and the (Stake), the location of the label is on the same surface as the code, day-night, time on, dusk to dawn and sensitivity selection switches. The consumer must set these switches prior to usage and then assemble the unit. This is detailed in the manual. This unit is a transmitter only, and the transmitter must be set to the same code as the (sold separately) receiver. The unit will not operate correctly prior to the above steps.