


PMC-004 Label and label location

Label information

- The PMC-004 notation is directly printed on the back of housing. No label is attached.
- Printing is strong and durable enough.

Notation and location



Back side