



User Manual

Wireless Keyboard

Model: KP-810-19S

Rev. 1.0

www.iPazzPort.com

Introduction:

This Mini Wireless Keyboard consists of keyboard and mouse touchpad which is designed small and portable size. It provides people a unique & capable tool to operate their personal computer wirelessly. it is widely used for:

- the people who need to be apart from their personal computer yet must control it for their presentation, teaching and lecturing with large screen or projector, up to 33 feet wireless operation distance provides you big free space to communicate with your audience.
- the people who want to sit at their easy and comfortable chair to view the internet content, network television, such as IPTV, or internet movies instead of physically change its channel, it is a really computer remote controller, of course not a TV remote controller.

Package:


Mini Wireless Keyboard 1
User manual 1

Features and specifications:

- ➤ Wireless connection
- QWERTY keyboard
- Support Multi-language
- ➤ Ultra sensitive Multi-touch
- Working voltage: 3.3V
- ➤ Power supply: DC 3V(1.5V AAA battery X 2)
- ➤ Portable size: 164.4x59x16.2mm
- ➤ Weight: 62g

How to use:


1. Remove battery cover to install battery, and take USB dongle out.



1.1.Push downward

1.2. Take USB Dongle out


2.Insert USB dongle into computer USB port and turn on keyboard.



- 3. Pair: in case of lose connection between USB dongle and keyboard, please follow below steps to do re-pair procedure:
- 3.1. Press button "Fn" and "F1" at the same time (about 3s);
- 3.2. Plug USB dongle into any USB port of your computer;
- 3.3. Approach mini keyboard to the USB dongle and re-pair is successful.

Note: The factory matching well, when keyboard connects the equipment without faction, according to methods mentioned above.

Function description of keyboard:




Function	Description	Operation	
5	Change operation directions	Press Fn+Esc	
RF	Pair with USB receiver	Press Fn+ F1	
→ >	Volume down	Press Fn+F2	
– (*)	Volume up	Press Fn+F3	
=	Mute	Press Fn+F4	
K	Previouse	Press Fn+F5	
H	Pause	Press Fn+F6	
₩	Next	Press Fn+F7	
♪	Return to home page	Press Fn+F8	
~	Return to upper	Press Fn+F9	
PrtSc	Print screen	Press Fn+F10	
Del	Delete	Press Fn+ ←	
Home	Home	Press Fn+9	
F12	F12	Press Fn+=	
F11	F11	Press Fn+-	
End	End	Press Fn+0	
Ins	Insert	Press Fn+8	
Ctrl+Alt+Del	Ctrl+Alt+Del	Press Fn+Enter	

Multi-touch application:

the touchpad supports various gesture, the related gesture and function is described below:

Touchpad Function	Mouse Function	Finger Gesture	Finger Action	Remark
Moving	Move Cursor		Slide one finger on the touchpad	
Middle botton click	Middle botton click		Tap the touchpad with two finger simultaneously	Scroll upward Scroll downward Scroll pages quicky when browse website
Vertical two finger scroll	Scroll middle key		Slide two finger vertically	Zoom in or out the picture when view pictures

WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal

Notice to customer:



This symbol on the battery indicates that the battery is to be collected separately.

The following apply only to users in European countries.

This battery is designed for separate collection at an appropriate collection point.

Do not dispose of as household waste

For more information, contact the retailer or local authorities in charge of waste management.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Compliance statement:

- 1: This device is verified to comply with Part 15 of the FCC Rules. Operation subject to the following two conditions:
- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.
- 2: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed

And used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

Notes: When you device disturbs the mini bluetooth keyboard, you can use the USB extended cable to connect the USB receiver to avoid the interference