



* R1 & R3 is OTP CPU only

Note: MR1.2,3,4

MR1	MR2	MR3	MR4
MR5	MR6	MR7	MR8
MR9	MR10	MR11	MR12
MR13	MR14	MR15	MR16
MR17	MR18	MR19	MR20
MR21	MR22	MR23	MR24
MR25	MR26	MR27	MR28
MR29	MR30	MR31	MR32

304 w/10N NIX 10000U

FCC ID# BRWXR-3 Figure 4.2.1 Transmitter Schematic Diagram

