



ST-69BTS Wireless portable bluetooth speaker USER MANUAL



Please read the instruction carefully
before operating the unit.

English

NOTE: If you have connected any Bluetooth devices before, press the POWER button (3) for 5 seconds to turn on the speaker. The speaker will reconnect with that device automatically and the indicator will flash blue quickly, then it becomes steadily lit.

Raising and lowering the volume.

- Press and hold in the volume buttons(2&4) to lower or raise the volume.
- An audible signal is emitted once either the highest or lowest volume level is reached.
- Sometimes volume adjustments made on your device will also affect volume output from the speaker.

Changing tracks/songs


To skip to the previous/next songs, press the [◀◀ Volume -] or [▶▶ Volume +] button to change.

Incoming calls

When you receive an incoming mobile phone, music audio will automatically mute. Once the call has ended, it depends entirely on you mobile phone whether the current track will return to playback or not.

Cable connection

To listen to the music using a wired connection, Connect your music device to the audio port using the included audio cable.




- The socket is only meant for connecting an audio source and not for use as a headphone outlet. When the cable is successfully connected, the display will be blue.
- The functions(2&3&4) on the speaker will not work with the cable connected. You must control the functions using the audio source device.
- The speaker volume(2&4) can not be adjusted in this mode.

CARE AND MAINTENANCE

Clean the product by wiping it with a soft dry cloth.
Never use solvent or abrasive cleaning agents.

GB - 2

CONTROLS IDENTIFICATION



1. Indicator light
2. [◀◀ Volume -] Previous / volume down button
3. [▶▶ POWER] On/off and play/pause button
4. [▶▶ Volume +] Next / volume up button
5. Speakers
6. RESET hole

POWER YOUR SYSTEM


Batteries

Operated by built-in Lithium battery or DC power.

Charging the speaker

Use the provide USB cable. Connect one end to the speaker and the other end to a computer or use an adaptor(sold separately) and connect it to a wall socket. The " POWER light" should be on.

- During charging the red LED will be lit. When charging is complete it will turn off.
- Please note that the USB cable can only be used for charging and not for data transfer. USB cable can be used during playback.



OPERATION

Turning the speaker on/off

1. Turn ON: Press and hold in POWER button(3) until the indicator begin flashing blue.
2. Turn OFF: Press and hold in POWER button(3) until the indicator turns red.

Establishing a wireless connection

In order to listen to audio from your mobile phone or other bluetooth device, you must first pair the devices with each other.

1. Turn off any other devices that are paired with your device.
2. Start the bluetooth function on the device before pairing.
3. If it is the first time you use the speaker system, press and hold the Power button to turn the system on. After 5s, the status indicator flashes blue with the frequency of 1s. Do not stop pressing and holding it, one second later, the status indicator will flash blue with frequency of 80 ms.
4. Place the device into bluetooth search mode. The device will begin searching for the speaker.
5. Select ST-69BTS from the list.
6. Select OK or yes to pair the devices.
7. If needed, use 0000 as the password.
8. The display will remain lit if the pairing is successful.

GB - 1

TROUBLE SHOOTING GUIDE

Problem	Solution
The speaker turns off automatically	Recharge the battery
No connection	<ul style="list-style-type: none">● Make sure the speaker is charged and that audio source is not out of range of the speaker.● Make sure that your bluetooth devices are properly paired.
Not functioning correctly	If the speaker is not functioning correctly, you can push the reset button by inserting a narrow object into the hole on the back of the speaker. The speaker will be turned off and you can then restart it.

Safety

- Never expose the product to fire as this could result in personal injury.
- Do not store the product in extremely cold or warm environments.
- Never dismantle the product.
- Never let children play with the product.
- Do not expose the product to dampness or moisture.

SPECIFICATIONS

Dimensions:	80 x 80 x76 mm
Weight:	Approx 150g
Battery type:	850 mAh lithium battery
Bluetooth version	V2.1+EDR
Operating time	Up to 5 hors at 60% volume
Charging time	Approx 2-3 hours
Max output	2x1.5 W
Charging voltage	5V
Working distance:	Up to 10 meters measured in open space. (Wall and structures may affect range of device)
Standard:	USB cable&line-in cable(included)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

GB - 3