

SBT602 User Manual

SHARPER  
IMAGE®

Bluetooth Speaker



User Guide  
SBT602

In the box



Location of Controls



1. [ << VOL- ] button: • Previous track (quickpress)  
• Decrease volume (hold)

2. [ >> VOL+ ] button: • Next track (quickpress)  
• Increase volume (hold)

3. [ ⏻ ] button: Power ON/OFF

4. Indicator light

5. [ PLAY/PAUSE ] button: Play/Pause music

6. [ Connect ] button: Connect to Bluetooth

7. Audio socket

8. Mini USB charging port




Charging the Bluetooth Speaker



1. Connect the small end of the USB charging cord into the Mini USB charging port on the back of the speaker.

2. Connect the other end of the USB cable to your computer's USB port.


3. The indicator light on the front of the speaker lights up RED when charging.


4. The indicator light on the front of the speaker turns off when finished charging.





PC


The USB cable can only be used for charging, not for any data transfer.

Make sure you charge the speaker for 8 hours before using it for the first time.

On a Blackberry


• Go to SETTINGS/OPTIONS > BLUETOOTH

• Enable BLUETOOTH




On an Android Phone

• Go to SETTINGS > BLUETOOTH > MENU > Search



On other Cell Phones/Devices

• Review the instruction manual that came with your phone/device.



Pairing the speaker with a Bluetooth enabled device


1. Turn the speaker on by pressing the [ ⏻ ] Power ON/OFF button. If you're using the speaker for the first time, press and hold the [ ⏻ ] Power ON/OFF button to turn the system on. After 4 seconds the audible signal is emitted.

2. The Indicator light will flash BLUE twice, followed by a RED flash.

3. Press the [ Connect ] button. The Indicator light will flash BLUE and RED.

4. Keep the speaker and Bluetooth enabled device within 3 feet of each other during the pairing process.


5. Set your mobile phone or other Bluetooth enabled device to search for Bluetooth devices.



within 3 feet

On an iPhone

• Go to SETTINGS > GENERAL > BLUETOOTH (Make sure Bluetooth is turned ON)



Using your Bluetooth Speaker


Powering ON/OFF

• To turn **ON**, press and hold the [ ⏻ ] button for 4 seconds.

• To turn **OFF**, press and hold the [ ⏻ ] button for 3 seconds.

Adjusting the volume

Press and hold the [ >> VOL+ ] button to increase the volume and the [ << VOL- ] button to decrease it to your desired level.


NOTE: You may also adjust the volume from your mobile phone's volume control.

Answering / Ending a call

Use the native controls on your mobile phone to answer and end a call.


To make a call

Dial the number and press the send button on your mobile phone. The call is automatically transferred to the speaker.



Caller ID

The speaker will read out the phone number of any incoming calls while connected to a Bluetooth enabled device.

NOTE: If your phone is set to answer within a few rings, it will answer and go to voicemail before the number is read allowed. Be sure to set your amount of rings higher on your mobile phone if you want this feature to work correctly.

Cable Connection

To listen to music using a wired connection, connect your music device to the audio port using the included audio cable.

NOTE:

The Audio port does not work as a headphone jack. Whenever you connect the audio cable, the status indicator will light up BLUE. The functions on the speaker will not work with the cable connected.

Playing Music

To enjoy wireless music on your Bluetooth Speaker, make sure you are connected to a Bluetooth enabled device. Once connected you can press PLAY on your Bluetooth device or you can press the [ >> ] button on the SBT602 Bluetooth Speaker.

Once playback has begun, you can control the music or answer phone calls from the control buttons of the Bluetooth speaker (with devices that have the AVRCP Bluetooth profile).

Safety instructions

Safety and operating instructions should be retained for future reference.

• Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged, such as the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the unit, or the unit has been exposed to moisture.

• To reduce the risk of fire or electrical shock, do not expose this product to rain or moisture. The unit must not be exposed to dripping and no object filled with liquids, such as a vase, should be placed on the unit.

• Please keep the unit in a well-ventilated environment.

• No naked flame sources such as candles should be placed on the unit.

• Disposal of this product should be in accordance with local regulations. If you are not sure how to proceed, contact your local authority.

• Clean only with a slightly moist, lint-free cloth.

• Do not install near any heat sources such as radiators, stoves or other apparatus that produce heat.

• Only use attachments/accessories specified by the manufacturer.


Most media enabled smart phones will display "Connected to phone audio and media" when connecting to the Bluetooth Speaker. This means you can make phone calls and enjoy your music.

Play / Pause

Press the [ PLAY/PAUSE ] button to pause the music. To resume music playback, press the [ PLAY/PAUSE ] button again.

Adjusting the volume

Press and hold the [ >> VOL+ ] button to increase the volume and the [ << VOL- ] button to decrease it to your desired level.

NOTE: You may also adjust the volume from your mobile phone's volume control.

Skiping Songs (With devices that have AVRCP Bluetooth profile)

Quickpress the [ >> VOL+ ] button to go to the next song Quickpress the [ << VOL- ] button to go to the previous song.

Receiving calls

When receiving a call, the music will stop playing automatically. You can transfer the call from the speaker to your phone, or you can power off the speaker for a private conversation. Once the call has ended, use your mobile phone to continue music playback.

Legal information

FCC Part 15:

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Re-orient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

\*This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.\*

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Limitation of Warranty:

• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

• REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Should you have any questions or problems concerning this product, please contact our customer service department at:

Customer Support:

☎ 1-877-768-8483 (Toll Free)

✉ cs@southerntelecom.com

Monday – Friday: 8AM – 10PM (EST)

www.southerntelecom.com

Limited Warranty

90 Days Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

SHARPER IMAGE®