

Bluetooth® Soundbar Speaker

Model: ITSB-408



Instruction Manual



Please read these instructions fully before using and keep for furture reference.


QUICK START GUIDE

1. Make sure to remove ALL items before discarding package. This includes:

- Bluetooth SOUNDBAR Speaker
- (2)Short Screws,(4)Long Screws and (2)Washers
- (2)Wall Mounted Shelfs
- Power Adaptor
- Audio Cable
- Instruction Manual

2. You MUST make the correct installation for the Wall Mounted Shelfs before use!

- CAUTON: To ensure that the main product and the Shelfs are stable. The Soundbar Speaker must never been used without the Wall Mounted Shelfs fully installed. More details, see page 2 for the assemby instructions.
- 3. Make sure the Speaker and the POWER SWITCH is Turned ON before using the Soundbar Speaker.



- 4. Connecting your smartphone, tablet or other audio device via Bluetooth.
 - Press the ODD to enter the Bluetooth mode, the Bluetooth indicator will flash blue.
 - Activate the Bluetooth function on the device(e.g. phone) to be paired and place it in search mode.
 - The phone will appear as "ALK-S650". Select this as the device to be connected.
 - Once connection has been established the Bluetooth indicator stays lit.
 - For rare cases, the phone may ask you to input "0000" (for zeros) as passwords.

CONTENTS

Safety Instructions	1
Accessories and Assembly	. 3
Buttons and Controls	3
General operation	. 4
Bluetooth Operation	. 4
Playing Audio	. 4
Troubleshooting	. 5
Important Information	6

PRODUCT SPECIFICATIONS		
Input Power	DC 5V, 1.0A	
Output Power	2×5W+10W	
Bluetooth Range	33'(10m)	
Battery Capacity	5200mAh Lithium Ion	
Inputs	3.5mm Audio Input	
Included	Soundbar Speaker(1x), Power Adaptor(1x), 3.5mm Audio Cable(1x), User Manual(1x), Wall-Mounted Shelf(2x), Short Screws(2x), Long Screws(4x), Washers(2x)	

DDODLICT SDECIEICATIONS

NOTE: As a result of continual improvements, the design and specications of this product are subject to change without notice.

Made in China.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Other trademarks and trade names are those of their respective owners.

SAFETY INSTRUCTIONS



The lightning flash with arrowhead within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO PREVENT RISK OF ELECTRIC SHOCK,

DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PROFESSIONAL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Before using the unit, be sure to read all operating instructions carefully, please note that these are general precautions and may not pertain to your unit. For example, this unit may not have the capability to be connected to an outdoor antenna.

- 1. Read these instructions All safety and operating instructions should be read before the product is operated.
- 2. Keep these instructions The safety and operating instructions should be retained for future reference.
- 3. Heed all warnings All warnings on the product and in the operating instruction manual should be adhered to.
- 4. Follow these instructions All operating and use instructions should be followed.
- 5. Do not use this apparatus near water. Do not use the product near water and moisture, for example: near a bathtub, washbowl, kitchen sink or laundry tub; in a wet basement; or near a swimming pool.
- 6. The product must not be exposed to dripping of splashing, and not object lled with liquid should be placed on top of the product.
- Clean only with slightly moist, lint-free cloth. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.
- 8. Do not block any ventilation openings. Install in accordance with the manufacturer?s instructions. Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should never be placed near or over a radiator or heat source. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer?s instructions have been adhered to.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers, that produce heat.
- 10. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not t into your outlet, consult an electrician for replacement of the obsolete outlet.
- 11. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 12. Only use attachments/accessories specied by the manufacturer.
- 13. Use only with the cart, stand, tripod, bracket or table specied by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 14. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 15. Refer all servicing to qualied service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture does not operate normally, or has been dropped.
- 16. Power source The product should be operated only from the adaptor model of "YNQX06G050100UL". If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.
- 17. Power lines An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
- 18. Overloading Do not overload wall outlets and extension cords as this can result in the risk of re or electric shock.
- 19. Object and liquid entry Never push objects of any kind into the product as they may touch dangerous voltage points or short out parts that could result in re or electric shock. Never spill or spray any type of liquid on the product.
- Service Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualied servicing personnel.

SAFETY INSTRUCTIONS

- 21. Replacement parts When replacement parts are required, be sure the service technician uses replacement parts specied by the manufacturer or those that have the same characteristics as the original part. Unauthorized substitutions may result in re or electric shock or other hazards.
- 22. Safety check Upon completion of any service or repairs to this product ask the service technician to perform safety checks to determine that the product is in proper operating condition.
- 23. Damage requiring service Unplug the product from the wall outlet and refer servicing to qualied service personnel under the following conditions:
 - A: when the power-supply cord or plug is damaged.
 - B: if liquid has been spilled or objects have fallen into the product.
 - C: if the product has been exposed to rain or water.
 - D: if the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment may result in damage and will often require extensive work by a qualied technician to restore the product to its normal operation.
 - E: if the product has been dropped or the cabinet damaged in any way.
 - F: when the product exhibits a distinct change in performance -this indicates a need for service.
- 24. Batteries A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

25. The marking information is located at the bottom of the apparatus.

Warning

Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus.

Caution:


- Use of control and adjustments or performance of procedures other than those specied here may result in hazardous radiation exposure.
- 2. If this product develops trouble, contact qualied service centers, and do not use the product in a defective state.

Usage

- Before use, choose unit installation location carefully. Avoid placing in direct sunlight or close to a source of heat. Also avoid locations subject to vibrations and excessive dust, cold or moisture. Keep away from sources that hum, such as transformers or motors.
- Do not open the cabinet as this might result in damage to the circuitry or electrical shock. If a foreign object should get into the set, contact your dealer.
- 3. When removing the power plug from the wall outlet, always pull directly on the plug, never pull the cord.
- 4. Do not attempt to clean the unit with chemical solvents as this might damage the nish. Use a clean, dry cloth.
- In order to shut off the power to this product completely, unplug the power cord from the wall outlet. Be sure to unplug the unit if you do not intend to use it for an extended period of time, such as while on vacation.
- 6. Keep this manual in a safe place for future reference.

ACCESSORIES AND ASSEMBLY

Included:




Assembly:

Besfore using the SPEAKER, the Wall Mounted Shelfs MUST be installed to ensure stability. DO NOT make the installed step while the unit is truned ON or plugged in. NOTE: Please remove protective film from all areas before use.

- 1. Find a wall with power supplies within the length of the power cable.
- 2. Find 2 screws(supplied) fitted the size of the hanging hole.
- 3. Measure the length between the hanging holes.
- 4. Mark the hanging holes on the wall.
- 5. Fixed Wall-Mounted Shelfs (shorter upward), snapping the wall, and then hit the screws through the shelf.
- 6. Hit the screws through shelf(the longer side).
- 7. Put the unit on the shelfs.
- 8. Now, insert the power adaptor into the power input socket of the unit and plug the adaptor to the power supply.

BUTTONS AND CONTROLS



- 1. Bluetooth indicator
- 2. Source button
- 3. AUX IN indicator
- 4. Battery indicator
- 5. Play/Pause
- 6. Volume+
- 7. Aux in port
- 8. Volume-
- 9. Power switch
- 10. Power input

LED INDICATIOR OPERATION

LED indicator	Color status	Description
Bluetooth indicator	Blinks blue	Speaker is in pairing mode.
	Solid blue	Speaker is paired.
AUX in indicator	Green	Speaker is in AUX in mode.
Battery indicator	Orange	Speaker is charging.
	Green	Speaker is fully charged.

NOTE: When the battery in low voltage, it will warning.

GENERAL OPERATION

Preparation

Connect the adapter to the power input socket on the side panel of the unit.

Wake up the unit

Press the power switch to turn the unit on or off.

Select mode

Press the SOURCE button on the side panel to select the Bluetooth or AUX mode.

Adjust the volume

Press the $| \P | \rangle$ / $| \P |$ to adjust the volume to a comfortable level. Listen to the radio at high volume level may destroy the hearing. Avoid listening at high volume level for long time. (press and hold the $| \P | \rangle$ / $| \P |$ to the maxinum/ minimun sound, it will warning.)

Play/ Pause

Press the ►II to pause the playback, press again to resume.

BLUETOOTH OPERATION

- 1. Press the (1) to enter the Bluetooth mode, the Bluetooth indicator will flash blue.
- 2. Activate the Bluetooth function on the device(e.g. phone) to be paired and place it in search mode.
- 3. The phone will appear as "ALK-S650". Select this as the device to be connected.
- 4. Once connection has been established the Bluetooth indicator stays lit.
- 5. For rare cases, the phone may ask you to input "0000" (for zeros) as passwords.
- 6. To disconnect the devices: turn off the Bluetooth function on your device and unpair with your speaker. Then follow the STEPS 1-5 to pair with anew device.

NOTE: The unit can only connect with one device at a time and please make the pairing operation if the device is out of 10 meters range.

PLAYING AUDIO

- 1. Use the 3.5mm audio cable to connect the Speaker with the Audio device such as Mp3, Mp4,tablets.
- 2. Press the 🗯 to enter the AUX in mode. The AUX in indicator lights solid green.
- 3. Your Audio device(MP3/MP4/Tablets)controls the music playback.
- 4. You can only adjust the volume by pressing the II) / II .

TROUBLE SHOOTING

If you're experiencing problem with your apparatus, there are some quick and easy checks that you can do to help to solve problems.

The unit does not work.

Correctly plug the mains into the power supply? Does the socket that is being used have power? Power off the unit then power on again.

No sound from speakers.

Is the volume control set at minimum?
Turn up the volume of the connected device.

Bluetooth not connected.

Check if the BT device is in searched mode.

Disconnect the paired device and connect again.

If the device is out of the Bluetooth range (10m), please put the device within the Bluetooth range and manually make connection again if the devices are disconnected.

IMPORTANT INFORMATION

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

WARNING: Any changes or modications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT INFORMATION

California Prop 65 Warning

"WARNING" This product contains chemicals known to the State of California to cause birth defects or other reproductive harm. For more information on these regulations and a list of chemicals, log on the following website address: https://www.oehha.ca.gov/prop65.html

NOTE: This user manual has provided proper instructions to the users of the device, as well as usage restrictions, including the limits of exposure durations. The device is designed for reliable performance, and the user manual states detailed installations, proper operations, as well as special usage conditions, which comply with SAR and RF eld strength limits. Users of this product should carefully study the user manual before using this device.

INDUSTRY CANADA:

This equipment complies with Industry Canada license -exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autoris?e aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radio?lectrique subi, m?me si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Warning

-English:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

-French:

le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'explotation est autorisée aux deux conditons suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."