

Customer Driven

March 28, 2014,

To whom it may concern:

The RF power for the 1402 (HS6200) is only set during ATE. There are no user adjustable power level controls. Once it is set in the factory it cannot be changed by the user.

Regards,

Karl Knoblock

Senior Electronics Engineer

HM Electronics, Inc. | 14110 Stowe Drive | Poway, CA 92064 phone: 800.848.4468 | fax: 858.452.7207 | www.hme.com