


BS500 Transceiver Board Top Side



FCC

BS114

SW	OFF	ON
1	Lane	Lane
2	Super	Super
3	HF OFF	HF ON
4	-	-

S1
ON OFF


S2
STATUS

S3
CHANNEL

SQUELCH
ADJUST

BS500 Switcher Board

Bottom Side



BS500 Switcher Board Top Side

