

Figure 5 41D2047A MXi Assembly Diagram sht1 Rev 0




Figure 6 41D2141 MXi Wiring Schematic sht1 Rev 0




Figure 8 21B1473 MXi Front End UHF DTV Driver Assembly sht1 Rev 5.1




Figure 9 11A1354 MXi Front End UHF DTV Driver Schematic sht1 Rev 2.1




Figure 10 21B1951A1 IPA Final Assembly sht1 Rev 2





Figure 11 21B1950S1 IPA Schematic Diagram sht1 Rev 0.1






Figure 12 21B1751 Single Pallet Amplifier sht1 Rev 0




Figure 13 21B1751S Half Pallet Schematic sht1 Rev 2




Figure 14 11A2142S1 Pallet Circuit Schematic sht1 Rev 2




Figure 15 10A2121A3 UHF Bi-Directional Coupler Assembly sht1 Rev 0

MXi 1KW POWER SUPPLY




Figure 3 Power Supply Outline Drawing

PUB06-81 Rev 1 July 17, 2007 06-81-5 MXi 1kW Power Supply




Figure 4 41D2047A MXi Housing Assembly sht1 Rev 0




Figure 5 41D2141 MXi Dual Pallet Wiring Diagram sht1 Rev 0




Figure 23 MXi Controller Board Assembly Diagram 31C1897A2 sht1 Rev 2.2




Figure 24 MXi Controller Board Schematic 31C1897S1 sht1 Rev 2.3




Figure 25 MXi Controller Board Schematic 31C1897S2 sht2 Rev 2.3




Figure 26 MXi Controller Board Schematic 31C1897S3 sht3 Rev 2.3




Figure 27 MXi Controller Board Schematic 31C1897S4 sht4 Rev 2.3




Figure 28 MXi Controller Board Schematic 31C1897S5 sht5 Rev 2.3