

Figure 5  
Inside of the EUT




Figure 6  
Inside of the EUT




Figure 7  
Inside of the EUT




Figure 8  
Inside of the EUT




Figure 9  
Inside of the EUT




Figure 10  
Inside of the EUT




Figure 11  
Inside of the EUT




Figure 12  
Inside of the EUT




Figure 13  
Inside of the EUT




Figure 14  
Inside of the EUT




Figure 15  
Inside of the EUT




Figure 16  
Inside of the EUT




Figure 17  
Inside of the EUT




Figure 18  
Inside of the EUT




Figure 19  
Adaptor of the EUT

