


# Oyster


## Quick Start Guide



D: Schnellstartanleitung F: Guide de démarrage rapide

IT: Guida per l'utente ES: Guía de inicio rápido P: Guia Rápido de Utilização

# Safety Information



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**

## IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electrical shock, fire, etc.:

1. Read these instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth. For stubborn stains, use a soft cloth dampened with a weak solution of mild detergent and water. Dry the apparatus immediately afterwards with a clean cloth. Do not use abrasive clothes, thinners, alcohol, or other chemical solvents, because they may damage the finish or remove the panel lettering.
7. Do not block any ventilation openings. The ventilation shall not be impeded by covering the ventilation openings with items, such as newspapers, table clothes, curtains, etc.
8. Do not install near any heat source such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

9. Do not defeat the safety purpose of the polarized or grounding - type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. The optimum operating temperature is 0°C~40°C.
11. The optimum humidity is 30%~80%.
12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. If the power cord is damaged, it must be repaired by a qualified repairer.
13. Only use attachments/accessories specified by the manufacturer.
14. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.




PORTABLE CART WARNING

15. Unplug this apparatus during lightning storms or when unused for long periods of time.
16. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
17. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
18. The mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
19. Please read Rating Labels at the back of the unit for power input and other safety information.


# English

## Charge



- 1 When Flashing RED, OYSTER requires charging.
- 2 Insert the DC jack into the rear of your OYSTER.
- 3 A YELLOW Light indicates OYSTER is charging.
- 4 A GREEN light indicates that OYSTER is charged.

## Power, Pair & Play




- 1 Activate Bluetooth on the device you wish to connect.
- 2 Press the ON•OFF button to switch on your OYSTER.
- 3 The BLUE light blinks to show it is in pairing mode. Select OYSTER in the Bluetooth settings of your device.
- 4 Once paired it will connect automatically and the blue light will turn solid.
- 5 When connected, OYSTER will appear in your device list and you are ready to PLAY. You can only connect OYSTER to one device at the same time.

Warning: Playing music at loud volumes can damage your hearing. Please listen responsibly.

## Line In



1




2




3

1 Insert the 3.5mm cable supplied into the rear of the device you are connecting and the other end into the AUX IN at the rear of OYSTER. Press 2 SOURCE until the LED indicator turns 3 WHITE.



## Receiving a Call



1



2

You can accept an incoming the call 1 using your OYSTER by pressing the 2  button. Press the 2  button to hang up.

# Legal Disclaimer

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **FCC RF Radiation Exposure Statement**

**Caution:** To maintain compliance with the FCC's RF exposure guidelines, place the unit at least 20cm from nearby persons.

***damson***

[www.damsonaudio.com](http://www.damsonaudio.com)