
Model 1884 – Label Location



Label located on radio module shield top of EUT