

Thunderbolt™ 4 / USB 4.0

Studio Mics
Micros de studio
Micrófonos de estudio

Headphone jack
Prise de casque
Conexión de auriculares



Windows Hello camera
Caméra Windows Hello
Cámara de Windows Hello

Power button
Bouton d'alimentation
Botón de encendido


Surface Slim Pen storage (pen sold separately)
Rangement du stylet mince Surface (stylet vendu séparément)
Almacenamiento del Surface Slim Pen (el lápiz se vende por separado)

Front-facing camera
Caméra à l'avant
Cámara frontal

Surface Connect port
Port Surface Connect
Puerto Surface Connect



aka.ms/LaptopStudioModes



Charge and store a Surface Slim Pen
Permet de charger et de ranger un stylet mince Surface
Cargar y almacenar un Surface Slim Pen

support.microsoft.com

 Microsoft Surface
Laptop Studio

©2021 Microsoft.



M1188447-001