


View of the EUT setup in vertical orientation



View of the EUT setup in Horizontal orientation



View of the EUT setup in Side orientation

