

Operational Description

Product description:

- 1, function: rolling code handheld wireless remote control
- 2, power supply: 12V dry cell
- 3, launch frequency: 433.92 MHz
- 4, data group: five groups

Operating instructions:

- 1, startup (press 'ON "and" OFF' at the same time for about 3-5 seconds until the LED on the top left corner has lightened up.)
- 2, press" SELECT" to select different data set. LED will move right in turn for each press (the remote control has five sets of data);
- 3, press "ON" or "OFF" to send data;
- 4, shutdown (press "ON" and "OFF" at the same time for about 3-5 seconds until the LED on the top left corner has put out);