

LABEL INFORMATION

EXACT LOCATION OF THE LABEL:

Label is located on the rear of the wall-mounting plate in the location shown:



LABEL



R800-26178A 5/20 Rev A