Photo Documentation



Page 1 of 4 50344114 002

<u>Product:</u> Nvite Reader <u>Type Identification:</u> NVR2001

Photographs of the Test Set-Up

Photograph 1: Set-up for Spurious Emissions (Front View)



Photograph 2: Set-up for Spurious Emissions (Back View 1)




Photo Documentation



Page 2 of 4 50344114 002

<u>Product:</u> Nvite Reader <u>Type Identification:</u> NVR2001

Photograph 3: Set-up for Spurious Emissions (Back View 2)



Photograph 4: Set-up for Conducted Testing (View 1)




Photo Documentation



Page 3 of 4 50344114 002

<u>Product:</u> Nvite Reader <u>Type Identification:</u> NVR2001

Photograph 5: Set-up for Conducted Testing (View 2)



Photograph 6: Set-up for AC mains (Front View)



Appendix X

Photo Documentation



Page 4 of 4 50344114 002

<u>Product:</u> Nvite Reader <u>Type Identification:</u> NVR2001

Photograph 7: Set-up for AC mains (Back View)

