

This REMOTE controller is designed to separately control your ceiling fan speed and light brightness. There are five buttons (HIGHT, MED, LOW, OFF, REV) to control the fan speed and off. The light Dimmer button will control the light brightness dimmer and ON/OFF. The red indicator on the transmitter will light when the button is pressed.