




Walkie Talkies

Includes: 2 Walkie Talkies



Functions:

*TO SPEAK:

In (ON) position, press and hold the (PUSH TO TALK) button. Then speak into Walkie Talkie to transmit voice.

MORSE CODE:


*In (ON) position, press and hold (PUSH TO TALK) button. Then press (MORSE CODE) button to transmit message.

ON/OFF/VOLUME:

Turn counter clockwise for (ON) position.
Turn clockwise to turn (OFF).
In (ON) position, adjust the volume level by turning up.

BATTERY REPLACEMENT

REPLACEMENT OF BATTERIES
MUST BE DONE BY ADULT.



This toy takes 2 x "9V" type batteries
(not included).

Non-rechargeable batteries are not to be recharged.
Rechargeable batteries are to be removed from the toy before being charged.
Rechargeable batteries are only to be charged under adult supervision.
Different types of batteries or new and used batteries are not to be mixed.
Batteries are to be inserted with the correct polarity.
Exhausted batteries are to be removed from the toy.
The supply terminals are not to be short-circuited.

Please keep this packaging since it contains important information.

To replace batteries, unscrew cover using a Phillips screwdriver. Note polarity of batteries, remove and replace with new batteries.



Caution:

Not recommended for children under three years of age. May contain small parts which present a choking hazard for young children.

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC ID: CIXAL61205

Questions or comments (Please Call)

1-888-TOYS-CDI

Or Write: Creative Designs International, Ltd.

2540 Metropolitan Drive, Trevose, PA 19053

VISIT US ON THE WEB AT www.cditoy.com

This product conforms to the safety
requirements of ASTM: F963.



0 45672 62952 4

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.