

Chapter 4 MAINTENANCE AND CHECK

4.1 ROUTINE MAINTENANCE



WARNING



Do not perform maintenance or repair by the customer.

Maintenance and repair by non-specialized maintenance personnel may result in fire or electric shock.

For internal maintenance and repair, please contact our sales department, a nearby branch office, branch office or sales office or our agent.



Be sure to turn off the main power when performing maintenance.

Doing so without turning off the power may cause electric shock.

Be sure to turn off the power before connecting or disconnecting the module or connecting or disconnecting the connector of the cable connected to the external device. Failure to do so may result in fire or failure.

If you must work while the power is turned on, do not touch internal parts or adjustment parts. Otherwise, electric shock or failure may occur.

Should any foreign matter such as water or metal enter the inside, first turn off the power of the device and turn off the breaker of the distribution board.

Please contact the sales office or the agency. If you use it as it is, there is a risk of fire, electric shock and failure.



It emits radio waves during operation. Do not enter within 75m in front of the antenna.