


# **M4 B1**

# **Quick Start Guide**

**Start Here**

# Phone overview




# Getting started

Please make sure that the phone is powered off before proceeding.

1. Open battery cover



2. Install Micro SIM & memory card



3. Install battery cover



# Buttons

**Power key:** To power off M4 B1, press and hold power key for a few seconds, then tap the options to confirm. When M4 B1 is on, press the power key once to activate or deactivate the screen.

**Home key:** Touch the key to return to the home screen. In idle screen, touch and hold the key recently accessed features.


**Menu key:** In idle screen, touch the key to view recently accessed features.

**Back key:** Touch to go back to the previous menu.




# Screen

M4 B1 features a 5.0" screen with 1280\*720 high resolution. Which make your phone looks fascinating.



# Screen lock

You can increase the security of your phone by selecting screen lock .Screen lock settings can be found under “Settings”>“Security”> “Screen lock”.




# Bluetooth

Turn Bluetooth on or off.

# Customize home screen


In standby mode, touch and hold an empty area to add set wallpapers. You can also remove items from the home screen, move items, add items to home screen to customize the home screen.



# Camera

M4 B1 is equipped with 8MP camera and a camcorder, which are designed for you to share wonderful moments with friends and family.


Adjust focus, exposure, zoom in or zoom out, switch between cameras and switch between the functions by flipping the icon on the screen.






# Internet

You can enjoy network by selecting 4G, WLAN, GSM. Enjoy music, videos, apps and news anywhere and anytime as you like.



# Make a call

You can make a call under the interface of Call log, contacts, favorites, message (which contains a phone number). In standby mode, press call key to make a call.



# Messaging

Touch and hold the text box to select an input method. You can insert smiley, picture, audio or video files and send to multiple recipients.




Once you start a new conversation,  
you'll see it listed here




# Email

The email app enables you to read, compose and send emails, and is configured to work with all the major email providers. M4 B1 supports multiple account mode, and you won't miss any email.




# Music

M4 B1 supports various music formats, different sound effects and 4 categorizing, i.e. Artists, Albums, , genres, Songs and Playlists.




# Photos

You will find it very easy to view all the photos. Flick right or left to move among images. Double-tap or pinch the photo to zoom. You can edit, share, print, and more.



# Cut, copy, and paste

Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then tap to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.



# FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a



Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

## **Specific Absorption Rate (SAR) information:**

SAR tests are conducted using standard

operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations(e.g. at the Limb and worn on the body), as required by the FCC. For body worn operation, this model phone has been tested and meets the FCC RF

exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 10mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guideline.