



10. SETUP PHOTOS


9 kHz – 30 MHz FRONT PHOTO




9 kHz – 30 MHz BACK PHOTO



30-1000 MHz FRONT PHOTO




30-1000 MHz BACK PHOTO




1-18 GHz FRONT PHOTO




1-18 GHz BACK PHOTO




18-40 GHz FRONT PHOTO + FUNDAMENTAL



18-40 GHz BACK PHOTO + FUNDAMENTAL




> 40 GHz FRONT PHOTO




> 40 GHz FRONT PHOTO



AC Line Conducted - Front



AC Line Conducted - Back



END OF REPORT