

LUXE™ 8000i FAMILY

INSTALLATION GUIDE FOR 8500i & 8700i

WARNING

- Only use the provided Equinox Payments A/C Power Adapter. Non-compliant power adapters may damage the device.
- Do not use if visibly damaged.
- Do not expose to temperatures below -10 °C or above 60 °C storage (not powered).
- Do not disassemble.
- Intended operating humidity range is 5% to 95% rh (non-condensing).
- This device is not designed or certified to be used in a flammable atmosphere such as a petrol station or chemical depot where there is a risk of explosion.
- Keep out of reach of children or pets.
- Do not incinerate or crush.

SAFETY INFORMATION

The Luxe Family of devices must be used within the operating conditions, electrical supply requirements, environmental conditions and connection requirements as specified below:

- Power Supply: These devices must be connected to the correct electrical supply. Connection to an inappropriate supply may damage or destroy this device(s), thereby invalidating its warranty(s).
- Only operate these devices within the temperature range of 0 °C - 45 °C.
- Hazardous Environments: These devices must NOT be installed in locations where there is danger of explosion.

FCC/IC COMPLIANCE

- FCC ID: COL-LUXE8500I
- IC: 2279B-LUXE8500I

This device complies with Part 15 of FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment fulfills the applicable FCC requirements with respect to RF exposure to electromagnetic fields, when used for the purpose and in the way it is intended and described.

WARNING: Changes or modifications to the equipment that are not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment.

- UL/cUL Listed E249765

If trouble is experienced with this device, please contact Equinox Payments at 1.877.497.3726 for repair or warranty information. If this device is causing harm to the telephone network, the telephone company may request that you disconnect this device until the problem is resolved.

NOTICES

If a power supply was NOT shipped with the Luxe terminal or if there is NOT an immediately available power supply to use with the Luxe terminal, use the following when selecting and using a suitable power supply:

- Must use Equinox P/N **870087-00x** or **870088-00x** or
- Must use a suitably safety Listed power supply, output rated 9-12Vdc 1A or greater AND must be a certified Limited Power Source (marked "LPS").

CLEANING DEVICE



WARNING:

- Do NOT use industrial strength or an abrasive cleaner as it may damage or scratch the device/screen.
- Do NOT immerse device in any liquid.
- Do NOT spray water or cleaner into MSR or Smart Card Reader slots or ports.

Apply distilled water or mild cleaner on to a soft, lint free cloth. To clean, gently wipe down the terminal.

Equinox Payments
9045 E. Pima Center Pkwy, Suite 3, Scottsdale, AZ 85258, USA | Tel: +1.877.497.3726 | Fax: +1.480.551.7811 | www.EquinoxPayments.com

© 2016 Brookfield Equinox LLC (DBA Equinox Payments), all rights reserved. Equinox Payments & the Equinox Payments logo are registered trademarks of Equinox Payments. Information within this guide may not match the terminal device and its accessories exactly and thus are subject to change. 940662-001E Rev. A 11/16

LUXE™ 8000i FAMILY

INSTALLATION GUIDE FOR 8500i & 8700i



SHIPPING CONTENTS*



Luxe 8000i Family
(8500i — 010390-00XE)
(8700i — 01039X-00XE)

* Contents may not match exactly as shown.




9 4 0 6 6 2 - 0 0 1 E

EQUINOX

LUXE™ 8000i FAMILY INSTALLATION GUIDE

STEP 1: Turn Terminal Over & Insert Cable

SIDE VIEW



NOTE: Use M3 threaded mounting screws (no more than 8mm of engagement; arranged in a 50mm x 50mm pattern). Screws not provided.

STEP 2: Angle and Push Cable In Against Terminal

ENLARGED VIEW



A Push Cable In at an Angle

STEP 3: Rotate Cable Down & Press Firmly to Lock in Place, then Screw to Secure

ENLARGED VIEW



NOTE: Use small Philips screwdriver (not provided) to install cable.

Use screwdriver to secure cable

A Rotate Down to Lock

STEP 4: Turn Terminal Over & Connect Power Source



NOTE: To remove cable, disconnect power source and then turn the terminal over. Use screwdriver to remove the screw from the cable end. Push cable end in (against the terminal), then lift (rotate) cable up to remove.

INSPECT SLOTS FOR FOREIGN OBJECTS



Visually inspect both the MSR & Smart Card Reader slots for any foreign objects that may obstruct, hamper or prevent the sliding or inserting of your card. If an object exists, do NOT use the device and immediately notify your supervisor for the device may be comprised. If no objects exists, use device as normal.

ACCESSORIES

To place an order, contact your Equinox Sales person or:

- 1.877.497.3726 or 480.551.7800
- info@equinoxpayments.com



Power Cord (810003-001)
NOTE: Use with 870088-001E.



Power Supply (870088-001E)
NOTE: Use with 810003-001.



R9 to DB9F Cable (810449-001E)
NOTE: Use with 810450-004E.



Power w/Ethernet Adapter Cable (810450-001E)



Power w/Serial Adapter Cable (810450-002E)



Power w/USB Adapter Cable (810450-003E)



PUSB Adapter (810450-004E)
NOTE: Use with 810449-001E.