





If the control's status indicator
continuously blinks, or if the LED
status indicator blinks red, the
remote is not working properly.
Check the battery level and
replace the batteries with new ones.
(2.1)

27MHz
2-0

FCC ID: CVT16773

CAUTION: This device is not to be used in the presence of
flammable or explosive materials. The device must be used in
accordance with the instructions provided in the user manual.
The device must be used in accordance with the instructions
provided in the user manual.