

## 5.2 Internal photograph


[VKS] side A



[VKS] side B



[Inside of shield] side A



The antenna connector shown is for inspection only.