


More Information Available Online

A comprehensive online user guide is available at pubs.shure.com.


Getting Started

Set up the system access point (MXCWAPT)




1. Connect the access point to Power over Ethernet (PoE) source to turn on the device.
2. Wait for the access point to scan the area.
3. The best Wi-Fi channel is automatically selected

Set up the microphone units (MXCW640)



1. Insert batteries to turn on the devices.
2. Wait for the microphone units to search for the default access point network (= default).
3. The units are ready when the LEDs stop flashing and the touchscreen displays the home-screen.

Check the audio

1. Turn on a microphone from one of the units.
2. Listen to the sound check on the other units' loudspeakers or headphone jacks.

Default system settings:

Maximum System Size

125 microphone devices

Wireless Encryption

Enabled

Wireless Network Name

default

Default meeting settings:

Meeting Mode

- Automatic (push to speak)
- No queue when the list is full

Maximum Total Speakers

8

Maximum Delegates

8