




## CONSTRUCTION PHOTOS OF EUT



Left Earbud



Brand: SENNHEISER, Model: CX400TW1 L



Black color















Right Earbud


Brand: SENNHEISER, Model: CX400TW1 R  
Black color








Earbud (main battery cell)











## Charging Case

Brand: SENNHEISER, Model: CX400TW1 C

Black color









Charging case (Main battery cell)



Charging Case  
Brand: SENNHEISER, Model: CX400TW1 C  
White color  
Charging case (alternative battery cell)





Earbud (alternative battery cell)



