

Display

Default screen PRESS

Display page

- Mute switch
- Receiver battery (EK)
- Transmitter battery (SK or SKM-S)
- Audio output level
- PEAK display
- Designation
- Frequency
- Channel
- Gain
- RF Signal strength

EW-D 470.200 MHz (01) +18 dB

Instruction Manual

LEDs

LINK LED	
	- Link ok - audio active
	- Link ok - audio muted or no capsule on SKM
	- Link ok - audio clip
	- No link
	- Link ok - Low transmitter battery
	- Device switched off

EK

SKM-S

SK

Sync

SKM-S short press

EK short press

SK short press

DATA LED	
	Bluetooth active to - sync with transmitter - connect with app
	Firmware update in progress

EK

SKM-S

SK

Cables

3.5 mm Y-Cable* Art.-No. 588180

3.5 mm - XLR male Art.-No. 588178

3.5 mm jack Art.-No. 586347

USB-C Power Art.-No. 575385

* for stacking two EK's

Menu

- Gain** (Output level) → +24 dB → +18 dB → +21 dB
- Output level** (Headphone) → 0 dB → -15 dB → -20 dB
- Headphone** (Mute switch) → ignored → active
- Mute switch** (Auto scan) → ignored → active
- Auto scan** (Channel) → 526.000 MHz (94)
- Channel** (Auto scan) → 93 → 94 → 526.000 MHz
- Frequency** (Channel) → 471 → 470.200 MHz → 526
- Brightness** (Frequency) → 80 → 60 % → 40
- Reset** (Brightness) → Yes → No → Yes

EW-D Smart Assist

Available on the App Store | Available on Google play

Sennheiser Documentation App

Available on the App Store | Available on Google play

Cheeseplate

OR

Stacking

Mounting instructions

Handling

SKM-S

ME 2

ME 3

ME 4

25 cm (10")

2...3 cm (1")

Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso | Instrucciones de manejo | Manual de instruções | Gebruiksaanwijzing | Instrukcja obsługi | Bruksanvisning | Betjenings vejledning | Käyttöohje | Οδηγίες λειτουργίας | Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 | 使用説明書 | 取扱説明書 | 사용 설명서

Setup

3.5 mm
3.5 mm
XLR
OR

Mute

SK SKM-S

EW-D Smart Assist

Download on the App Store GET IT ON Google Play

Sennheiser Documentation App

Download on the App Store GET IT ON Google Play

or online at www.sennheiser.com/download
EW-D_

Sennheiser electronic GmbH & Co. KG
Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Printed in Germany
Publ. 10/22, 592859/A01

Evolution Wireless Digital Portable

EW-DP EK, EW-D SK, EW-D SKM-S

Quick Guide
Kurzanleitung
Guide rapide
Guia rápida
Guía de inicio rápido
Guia rápido
Beknopte handleiding
Krótka instrukcja obsługi
Snabbguide

Kort vejledning
Pikaohje
Γρήγορος οδηγός
Kisa Kilavuz
Краткая инструкция
簡要說明
快速使用指南
クイックガイド
요약 안내서

SENNHEISER

Power Supply

EK

USB-C Power

OR

Powerbank

Battery

EK

BA 70 rechargeable battery (included)

optional: 2 AA batteries

EW-D Smart Assist

The EW-D Smart Assist app simplifies your workflow

- EW-D Smart Assist app provides automated setup, operation and monitoring using any iOS or Android device
- Intelligent setup automatically creates reliable wireless connections, no wireless expertise required
- Mobile access to all system settings centralizes control and eliminates the need for complicated menu navigation on each device
- Easy frequency allocation and wireless channel naming help to keep systems organized

Download on the App Store GET IT ON Google Play

EW-DP EK

EK - Variants

1G8 Variant

Battery

1 2 3

2 AA batteries (included)

*optional: BA 70 rechargeable battery

Battery

SK SKM-S

1 2 3 4

2 AA batteries (included)

*optional: BA 70 rechargeable battery

EW-DP EK

On/Off

EK SKM-S SK

Off -> On

short EK/SK/SKM-S on

On -> Off

long EK/SK/SKM-S off

Identify/Battery check

On -> Identify/Check

SK/SKM-S

short Identify/Check

LINK LED SK/SKM-S	≤ 100 %
≤ 60 %	
≤ 20 %	

Display of synced EK

EW-D SKM-S

EW-D SK