

CONSTRUCTED PHOTOS of EUT

7. EUT Mode: EM-XSW1 DUAL



8. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

9. EUT Mode: EM-XSW1 DUAL



10. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

11. EUT Mode: EM-XSW1 DUAL



12. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

13. EUT Mode: EM-XSW1 DUAL



14. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

15. EUT Mode: EM-XSW1 DUAL



16. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

17. EUT Mode: EM-XSW1 DUAL




18. EUT Mode: EM-XSW1 DUAL




CONSTRUCTED PHOTOS of EUT

7. EUT Mode: EM-XSW1




8. EUT Mode: EM-XSW1 (PCB Antenna)




CONSTRUCTED PHOTOS of EUT

9. EUT Mode: EM-XSW1




10. EUT Mode: EM-XSW1




CONSTRUCTED PHOTOS of EUT

11. EUT Mode: EM-XSW1




12. EUT Mode: EM-XSW1




CONSTRUCTED PHOTOS of EUT

13. EUT Mode: EM-XSW1




14. EUT Mode: EM-XSW1




CONSTRUCTED PHOTOS of EUT

15. EUT Mode: EM-XSW1




CONSTRUCTED PHOTOS of EUT

11. EUT Model: EM-XSW2




12. EUT Model: EM-XSW2




CONSTRUCTED PHOTOS of EUT

13. EUT Model: EM-XSW2




14. EUT Model: EM-XSW2



CONSTRUCTED PHOTOS of EUT

15. EUT Model: EM-XSW2




16. EUT Model: EM-XSW2




CONSTRUCTED PHOTOS of EUT

17. EUT Model: EM-XSW2




18. EUT Model: EM-XSW2




CONSTRUCTED PHOTOS of EUT

19. EUT Model: EM-XSW2




20. EUT Model: EM-XSW2




CONSTRUCTED PHOTOS of EUT

21. EUT Model: EM-XSW2



22. EUT Model: EM-XSW2



CONSTRUCTED PHOTOS of EUT

23. EUT Model: EM-XSW2 (PCB ANT)

