




Universal Serial Bus Keyboard (5141H)

BTC	S0	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	S17	S18	S19	S20
R0	60 Alt Left	46 Z	59 Korea Left	47 X	114 F3	110 Esc	52 M	51 N	50 B	49 V	48 C	85 Page UP	80 Home	75 Insert	45 > <						
R1		31 A	58 Ctrl Left	32 S	116 F5	115 F4	37 J	36 H	35 G	34 F	33 D	86 Page DN	81 End	76 Del							
R2	67 Japan	15 Back Space	57 Shift Right	13 + =	124 Print Screen	123 F12	8 &	9 *	10 (9	11) 0	12 - -	42 _(UK)	29 \	82 []	14 Japan						
R3	77 Left	1 ~ ,		2 ! _	126 Pause	125 Scroll Lock	7 ^	6 %	5 \$ 4	4 # 3	3 @ 2	89 →	84 ↓	79 ←	56 Japan						
R4		43 Enter	64 Ctrl Right	28 }]	122 F11	121 F10	23 U	24 I	25 O	26 P	27 { [	105 -	106 +	83 ↑							
R5	62 Alt Right	91 7 Home		96 8 ↑	120 F9	119 F8	38 K	39 L	40 : ;	41 " ,	101 9 Pg Up	100 *	95 /	90 Num Lock	107 Brazil						
R6	65 Japan	92 4 ←	66 Korea Right	97 5 ↑	118 F7	117 F6	53 < ,	54 > .	55 ? /	61 Space Bar	102 6 →	103 3 Pg Dn	98 2 ↓	93 1 End	78 Right						
R7		16 Tab	44 Shift Left	17 Q	112 F1	113 F2	22 Y	21 T	20 R	19 E	18 W	99 0 Ins	104 . Del	108 Enter (Pad)							