




BTC 9001A PS/2 Keyboard

90000/90002 /9001A

12/17/98

BTC	S0	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15	S16	S17	S18
R0	121	F10							45 102 KEY			77 Left	67 Japan	65 Japan	130	138			
R1	35	G	37	33	32	47	76	46	81 End	86 Page DN			60 Alt Left			92 4 ←	97 5		107 Brazil
R2	8	& 7	123 F12	124 Print Screen	13	15 Back Space	115 F4	116 F5	80 Home	85 Page UP	56 Japan		78 Right	14 Japan	66 Japan	91 7 Home	96 8 ↑	82 F2	113
R3	9	* 8	6	5	4	3	125 Scroll Lock	114 F3	1 ~ ,	126 Pause					58 Ctrl Left	89	84	79 ←	110 Esc
R4	25	O	26	122	27	31	75 Insert	28 }	42 \ (UK)	43 Enter	57 Shift Right				143 Power	105	106 +	83 ↑	112 F1
R5	10	(9	120 F9	38 K	39	40	41 "	52 M	51 N	29 \			62 Alt Right	144 Sleep	100	100 *	95 /	90 Num Lock	101 9 Pg Up
R6	11	) 0	118 F7	117 F6	50	49	53 < ,	54 > .	55 ? /	61 Space Bar			63 Korea Right	64 Ctrl Right	103 3 Pg Dn	103	98 2 ↓	93 1 End	102 6 →
R7	23	U	21 T	20 R	19	18	17 Q	48 C	16 Tab	30 Caps Lock	44 Shift Left		59 Korea Left	145 Wake up	99 0 Ins	104 Del	108 Enter (Pad)	2 !	1

● from S10 – S14 only NO.14,56,66 have no phantom key others have phantom state

● In Japanese keys(NO.14,56,65,66,67) just NO.14,56 must test 3 keys combination