


 <p>1</p>  <p>2</p>  <p>3</p> 	<p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. <p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. 	<p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. <p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. 	<p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. <p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select. 	<p>English Trackpad gestures</p> <ol style="list-style-type: none"> One finger slide or tap – point, move. <ul style="list-style-type: none"> *Left edge: Recent Apps. *Right edge: Windows Charms. *Bottom edge: App Bar. Two fingers swipe <ul style="list-style-type: none"> – vertical and horizontal scrolling. *Zoom: Enable. *Rotate: Enable. *Vertical – Up: Nothing. *Vertical – Down: Nothing. *Horizontal – Left: Nothing. *Horizontal – Right: Nothing. Three fingers swipe – page navigation. <ul style="list-style-type: none"> *Vertical – Up: App Search. *Vertical – Down: Windows Start. *Horizontal – Left: Snap windows Left. *Horizontal – Right: Snap windows Right. <p>Trackpad features</p> <ol style="list-style-type: none"> Left button click Press the left button for mouse click. Right button click Press the right button for right-button mouse click. Both Buttons Press both buttons for the middle button click. Tap to select Enable tap to select.
--	---	---	---	---

