



FUWC

Refer antenna specification for external antenna as there are some confidential installation instruction.



①




②



③



④



⑤



⑥

