

4. Internal Photograph of the Host

Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)


Bluetooth Module




Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)



Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)


WLAN Antenna <Tx / Rx>



Host: (FUJITSU LIMITED / Q572)




Host: (FUJITSU LIMITED / Q572)



Host: (FUJITSU LIMITED / Q572)

Bluetooth Antenna <Tx / Rx>



Host: (FUJITSU LIMITED / Q572)

