View of I/O Port

Inner View of EUT-1

Inner View of EUT-2


Inner View of EUT-3

Front View of Main Board

Front View of Main Board

View of Module Location

View of Module

View of Antenna Location