
WARNING **ORBI PRIME** ORBI Prime Glasses Do not try to fold the temples of the QUICK START GUIDE glasses, because it will break the device: USB charging cable Rear strap Water resistant EVA Case Carabiners Belt QUICK START TIPS Lens cloth Insert MicroSD Card with Speed Class V30 (U3) or higher, formatted to the FAT32 file system. Replaceable nose pieces Power On for the first time: Click the MODE button and then press the **POWER** button for 2 seconds. Download our app via the QR code below, and pair the device via WiFi using its unique name and the password shown here: You're ready to go! To get the full information about ORBI Prime please read the User Manual available at: orbiprime.com/ORBI-Prime-User-Manual.pdf Version 1.0 March 2019 2 GETTING STARTED **RECORDING VIDEO / PHOTO** WITH THE ORBI PRIME WITH-OUT MOBILE DEVICE POWER ON Before first use, activate ORBI Prime. Click the RECORDING VIDEO MODE button once, then press the POWER

button for 2 seconds to turn on the device. From then on, press and hold the POWER button for 2 seconds to turn ORBI Prime on or off.

CHARGING THE BATTERY

plug the large end of the charger into an



- Turn on the device.

- Press the SHUTTER button to start recording. Press the SHUTTER button again to stop recording.

TAKING PHOTOGRAPHS - Turn on the device.

- Press the MODE button to switch to

photo capture mode. - Press SHUTTER button to take a photo.

RECORDING VIDEO / PHOTO USING MOBILE APP


1. Download and install the ORBI 360 app. 2. Pair your eyewear with the phone. With the eyewear turned on, connect to it via

Wi-Fi. 3. Use the mobile app to take photos or videos.

7




Plug the small end of the charger into the MicroUSB socket on the ORBI Prime and electrical socket.



INSERTING MICROSD CARD

A memory card must be inserted into the ORBI Prime in order to record videos or ORBI Prime supports MicroSD Cards

Speed Class V30 (U3) and higher, 8-128Gb, formatted to a FAT32 file system. HINT: You can use the utility on our website to format your MicroSD card: orbiprime.com/fat32.zip



5

RECOMMENDATIONS

PUT ORBI PRIME ON OVER YOUR HAIR



HOW TO PLUG IN THE STRAP

