


iHome

Model: iBT920



COLOR CHANGING SPLASH RESISTANT BOOMBOX




Quick Start Guide

Questions? Visit ihome.com

Front

TOP PANEL



Volume Button

- Short press volume - button to decrease volume. When playing music, long press to play the previous song. When in FM mode, long press to select the previous radio station.
- Short press volume + button to increase volume. When playing music, long press to play the next song. When in FM mode, long press to select the next radio station.

Light Button

- Short press to change light modes, long press to turn off the light.

Mode Button

- long press to switch mode, short press for EQ effects select.


Power On/Off

- Long press for 2 seconds to power on/off.

Play/Pause Button

- Short press to play/pause.
- In Bluetooth mode, long press for 2 seconds to manually pair. Long press for 5 seconds to reset Bluetooth.
- When in FM mode, long press to automatically search for channels.

REAR JACK PANEL




Insert TF card to play MP3 music. Max workable capacity: 32 GB

Note: TF cards and USB drives with capacity larger than 32GB may not work.

Insert the USB drive to play MP3 music. Max workable capacity: 32 GB

CHARGING THE SPEAKER



LED STATUS INDICATORS:

Indicator	Color	Status
●	RED	Charging
●	OFF	Fully charged

*Charging indicator located on rear of unit above the USB-C port.

BLUETOOTH

●	BLUE	Pairing (fast flashing)
●	BLUE	BT Connected (slow flashing)

*Bluetooth indicator located on rear of unit above the USB-C port.

BLUETOOTH CONNECTION OPERATION

- The first time the iBT920 is powered on it will enter BT pairing mode.
- Select "iHome iBT920" on your device to pair.
 - To manually pair BT change to BT mode and press and hold the Play button for 2 seconds.
 - Long press the play/pause button for 5 seconds to reset BT.


WIRELESS STEREO

(REQUIRES 2 iBT920 SPEAKERS)

1. Pair one iBT920 unit to your device via Bluetooth.
2. Power on the second iBT920 unit.
3. Double press the power button on each unit.
4. When both units are linked, will announce "Left Channel", "Right Channel" respectively.
5. The units will link automatically the next time they are powered on together.
6. To remove wireless stereo and reset BT pairing, press and hold the Play button for 5 seconds on each unit.

JACK PANEL COVER

Before using near water, please be sure the jack panel cover is closed securely.



LOW BATTERY VOICE PROMPT

When "Low Battery" voice prompt is announced, please recharge the battery accordingly.

Back

IMPORTANT SAFETY INSTRUCTIONS

Please heed all warnings, read and follow all instructions and keep these instructions handy for future reference.

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Heat – This product should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- Only use attachments/accessories specified or supplied by the manufacturer.
- Unplug this product during lightning storms or when unused for long periods of time.
- Damage Requiring Service – This product should be serviced by qualified service personnel when:
 - Plug has been damaged.
 - Objects have fallen into or liquid has been spilled into the opened Jack Panel cover.
 - The unit has been dropped or the enclosure damaged.
 - The unit exhibits a marked change in performance or does not operate normally.
- 7. No naked flame sources, such as lighted candles, should be placed on this product.
- 8. Attention should be drawn to the environmental aspects of battery disposal.
- 9. This product is suitable for use in tropical and/or moderate climates.
- 10. Do not dispose of batteries in the household trash or fire.
- 11. Unplug unit and clean only with damp cloth. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.
- 12. CAUTION! Risk of explosion if the battery is replaced by an incorrect type.
- 13. If the unit is to be unused for an extended period of time, such as a month or longer, charge the unit fully before storage. Always use a UL/ETL certified charging adapter (not included), and the supplied USB charging cable.

WARNING/DISPOSAL OF UNIT

Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To dispose of the unit, follow the instructions below:

- Never dispose of used batteries/electronics with ordinary solid wastes since they may contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations.
- Many electronics retailers now recycle batteries and other electronic components at no charge. To find a drop-off location near you, visit www.call2recycle.org.

FCC INFORMATION

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Information

The device complies with ISED RF exposure requirement, users can obtain Canadian information on RF exposure and compliance.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

L'appareil est conforme aux exigences d'exposition RF ISED, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur à utiliser l'équipement.

CAN ICES-3 (B) / NMB-3(B)

ONE YEAR LIMITED WARRANTY

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase. Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service. If service is required, please contact Customer Service at ihomeaudio.com/support/contact to obtain a Return Authorization Number and shipping instructions. A copy of the sales receipt is required to validate in-warranty coverage. If proof of purchase cannot be produced, the product will be deemed out-of-warranty. The date of purchase, vendor, product model number, and purchase price must be legible and verifiable.

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner. This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages.

(Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

© 2024 SDI Technologies, Inc. All rights reserved.
 Questions? Visit www.ihome.com