


Frequency Hopper

ATTEN 40dB
RL 30.0dBm

10dB/

Δ MKR -68.84dB
-17.30MHz




CENTER 902.00MHz SPAN 20.00MHz
*RBW 300kHz VBW 300kHz *SWP 100ms

ATTEN 40dB
RL 30.0dBm

10dB/


Δ MKR -66.84dB
11.23MHz



CENTER 928.00MHz SPAN 20.00MHz
*RBW 300kHz VBW 300kHz *SWP 100ms


DTS Mode

ATTEN 40dB ΔMKR -68.50dB
RL 30.0dBm 10dB/ -14.37MHz



CENTER 902.00MHz SPAN 20.00MHz
*RBW 300kHz VBW 300kHz *SWP 100ms

ATTEN 40dB ΔMKR -67.17dB
RL 30.0dBm 10dB/ 17.50MHz



CENTER 928.00MHz SPAN 20.00MHz
*RBW 300kHz VBW 300kHz *SWP 100ms