

Hi Tim,

Below please find the reply upon your last comment, thanks!!

1. Sorry for my typos on my last reply, the frequency band used should be CH1-11 (2412-2462MHz), FYI.
2. Please find the modified user manual attached.
3. Please find again for the modified user manual attached.

Eric 0728