
The Client Manager main window displays the status of your active configuration profile and the quality of your connection. Menu items are available to add/edit your profile and to select advanced Client Manager options.

From the main Client Manager window, select Actions in the menu bar. Select the Add/Edit Configuration Profile option to activate a wireless profile from the pull-down menu or to add, edit, or delete a user-defined wireless profile.

Client Manager provides options in the configuration process to:

- describe your profile (for example, my office)
- identify your network (ID name of access point)
- set security/encryption
- set power management (default is power consumption high performance)
- set TCP/IP behavior (requires an IP address from your system administrator).

CAUTION:

In order to comply with the FCC and Industry Canada RF Exposure requirements, it is recommended, when using NEC Versa L320 Notebook Computer with built-in wireless LAN module, a separation distance of at least 2.5 cm must be maintained between the antenna of this device and all persons.