

41. Front View Of H.D.D.

42. Back View Of H.D.D.



- 43. Front View Of FDD/CD-ROM COMBO
- 44. Back View Of FDD/CD-ROM COMBO



- 45. Front View Of FDD/DVD-ROM COMBO
- 46. Back View Of FDD/DVD-ROM COMBO



- 47. Front View Of Battery
- 48. Back View Of Battery



- 49. Front View Of External Battery
- 50. Back View Of External Battery



- 51. Front View Of Adapter (Mode 1)
- 52. Back View Of Adapter (Mode 1)




53. Front View Of Adapter (Mode 2)

54. Back View Of Adapter (Mode 2)




- 55. Inner View Of Adapter (Mode 1)
- 56. Inner View Of Adapter (Mode 2)





- 57. Component Side Of Adapter (Mode 1)
- 58. Solder Side Of Adapter (Mode 1)



- 59. Component Side Of Adapter (Mode 2)
- 60. Solder Side Of Adapter (Mode 2)

