




**EUT – (WF6972) Base-set: Chassis View, bottom Cover Removed**




**EUT – (WF6972) Base-set Main Boards with antenna Component View -1**




**EUT – (WF6972) Base-set Main Boards with antenna Component View -2**



**EUT – (WF6972) Base-set RF Board Detail View (RF Shielding Removed)**



**EUT –(WF6972) Base-set Antenna View**




**EUT – (WF6972) Base-set power supply**




**EUT – (WF6972 & WF6909) Hand-set: (Back View 2 with battery compartment cover removed)**




**EUT – (WF6972 & WF6909) Hand-set: Back (Cover Removed View)**




**EUT – (WF6972 & WF6909) Hand-set Main Board Component View**




**EUT – (WF6972 & WF6909) Hand-set RF Board Component Detail View (RF Shielding removed)**




**EUT – (WF6972 & WF6909) Hand-set Antenna Detail View**



**EUT – (WF6972 & WF6909) Hand-set: Battery View**



**EUT – (WF6909) Handset charger power supply**



**END OF REPORT**