


Top view (w/o mag. case,
rear case and door)

Coax cable routed under plastic Wifi
Support piece to front of unit


Old Antenna and coax connection;
not used and may or may not be
loaded on board




Wifi Module

Coax cable to 'SEC' connection,
other end to antenna PCB board

Left/door side view (w/o mag.
Case and rear case)



Right view (w/o mag. Case and rear case)





Right view (w/o mag. Case, front case and rear case)



Antenna PCB

Additional Right and close up views (w/o mag. Case, front case and rear case)



Antenna PCB