


FinePix A200 Camera Block Diagram




DR SW

X301
CSTCW48M0X11066
-R0
48MHz OSC



IC304 FF4146
(WCS_MCM) 3.3V

from EVR
from CISC



XSCL.RES
LP.FR.GCP
FRYS.XSCL
FRYP.DY

LCDDATA
[5:0]


LCD

BL

Removable MEDIA

CARD_ON

from CISC



STRB_DIS
STRB_SY
STRB_COK
STRB_FULL
STRB_CC

STRB_BLK

CTL IC

IC602
UPC5023GR-178-8J

USB

CARD_ON to MEDIA

YUSABURI_ON to LCD
LCD_ON

GSEL_V_TH STRB_CHG
from EVR