Location of
FCC/IC Label
(Internal)

FlexWave™ URH - PCS
Remote Unit
Location of FCC/IC ID (Internal)

Location of
FCC/IC Label
(External)

FlexWave™ URH
Remote Unit
Location of FCC/IC ID (External)