

Warranty

MAXRAD, Inc. warrants that at the time of shipment the products furnished by MAXRAD, Inc. are free of defects in material and workmanship. MAXRAD, Inc. makes no other warranty, express or implied, with respect to its products. MAXRAD, Inc. will repair or replace, at its option, without charge, any MAXRAD product which fails within two years from date of purchase. This warranty does not extend to any of our products which have been subjected to misuse, neglect, accident, improper installation, improper application, nor shall it extend to units which have been repaired, disassembled or substantially altered outside the MAXRAD factory.

MAXRAD, Inc. reserves the right to inspect all defective products which must be returned to the MAXRAD, Inc. factory freight prepaid. No products will be accepted for replacement or repair without prior written approval. In all cases, final warranty disposition of defective products will be determined by MAXRAD, Inc. The warranty period shall not be extended beyond its original term with respect to any part or parts repaired or replaced by MAXRAD, Inc.

MAXRAD, INC. WILL NOT BE RESPONSIBLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES DUE TO FAILURE OF A MAXRAD, INC. PRODUCT UNDER THIS WARRANTY WHETHER SUCH CLAIM IS BASED ON TORT (INCLUDING NEGLIGENCE), CONTRACT, ANY THEORY OF STRICT LIABILITY OR REGULATORY ACTION.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. THE ABOVE STATED WARRANTIES ARE GIVEN IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND MAXRAD INC. HEREBY SPECIFICALLY DISCLAIMS ALL IMPLIED WARRANTIES INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE AND ANY BASED UPON USAGE OF TRADE OR COURSE OF DEALING.


RETURNS

In the unlikely event a defect occurs in this product, please work through the dealer or distributor from which this product was purchased. Maxrad provides complete service and support to all of its dealers and distributors.

MAXRADTM

**4350 Chandler Drive
Hanover Park, IL 60133**

MSP 24013120(3 dbi)



MPAB7 ADJUSTABLE MOUNT INSTRUCTION SHEET

© 2002 MAXRAD, Inc.
All Rights Reserved

Part #: MIS-MPAB7
Rev. A

MPAB7 TILT MOUNTING BRACKET

The MPAB7 tilt mounting bracket can be used with the larger (13 dB and 18dB) MAXRAD "XF" type directional panel antennas or MSP sector panel antennas to provide down or up tilt mounting to a mast up to 2.88 inch O.D. (2.5 inch sched 40 pipe)

1. Assemble mount to antenna using the hardware provided as described in figure 2. For down tilt mounting, the bracket assembly with the longer threaded rods shall be mounted to the top of the antenna. For up tilt mounting, the bracket assembly with the longer threaded rods shall be mounted to the bottom of the antenna. Spacing references for down tilt (L1, L2) will be as shown in figure 2. Spacing references for up tilt (L1, L2) will be opposite as shown in figure 2.
2. Adjust the nuts nearest the antenna to positions that will provide the tilt angle required. Refer to Figure 1 and Figure 2 for position requirements.
3. Assemble the antenna to the mast as shown in Figure 2. Fine adjustment to the tilt angle can be made after the antenna has been mounted to the mast.




FIGURE 1




FIGURE 2