


Hardware Installation

1. You can connect the receiver to a USB port.

Connecting to a USB port




2. Install two AA batteries in the mouse.
3. Turn on your computer.
4. After you open Windows, please press the button under the receiver first and then press the button under the mouse for channel setting.

Warning:

1. Please do not use the wireless mouse on a desk which is made of glass, mirror, iron, or black velvet. Also, a flat surface is necessary or the optical sensor will error easily. If you use the wireless mouse on a desk that is made of metal, try using a pad and reduce the receiving distance.
2. Before the first installation is completed (channel setting ready), the mouse will not work in DOS.
3. The wireless mouse channel provides 256 ID-codes, and it automatically selects the ID # for your mouse. You can only set up one wireless mouse at a time. But if you have additional wireless mouse sets in an area of 10 square meters, more interference will occur between the receiver and your mouse.
4. If you feel the mouse does not move smooth as usual, then the batteries have lost their charge, so please replace them. You should set up the channel every time you replace the batteries.
5. The wireless mouse with radio frequency gives you free movement and an enjoyable experience. For optimal performance, place the receiver at least 8 inches (about 20 cm) away from the mouse and other electrical devices, such as the computer, monitor, and etc.
6. Press any button on the mouse when the mouse is in power saving mode.

Factory Setting



Button Assignments

The Button Assignment feature lets you work in a more efficient way because you can assign the most frequently used commands in Windows to the mouse buttons.

Magic-Roller Press the “Magic-Roller” to surf the Internet and Windows documents

Left Button Provides traditional mouse functions such as click, double click and drag.

Right Button You can assign this button frequently used keyboard and mouse functions in addition to features like EasyJump, Auto-Panning, Zoom, etc.

Roller Button You can assign this button frequently used keyboard and mouse functions in addition to features like EasyJump, Auto-Panning, Zoom, etc

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation..